



Allens
Music Centre

Hit the right note

RS800

Ringway

SPECIFICATIONS

Keyboard		Upper keyboard :61 Lower keyboard:61 Pedal keyboard:25
	After Touch(Sensitivity)	Upper keyboard Lower keyboard
	After Touch (Pitch)	Upper keyboard Lower keyboard
	Sensitivity	16 levels
	Split	Lead voice 1/2 Pedal keyboard 1/2
Registration	Pedal	Mono/Poly
	Registration Memory	M, 1-16, D
	Registration Bank	A, B, C, D
	Registration Group	Multiple files (>=20) 、 power saved, USB disk
Voice	Registration Shift	Shift / User
	Voice Sections	Upper keyboard 1/2 Lead voice 1/2 lower keyboard 1/2 Pedal keyboard 1/2
	Preset voice	365
	Voice control	Volume Pad Transpose Tune Ocative Attack Decay Release Delay vibrato rate、 Vibrato depth、 Vibrato delay Resonance Cut.Freq
	Slide	Lead Voice 1 / 2
EFFECT	Slide setting	On/Off、 Time
	Keyboard Percussion	14 drum group; 2 set of user custom drum set
	Sustain	Upper keyboard Voice Lower keyboard Voice Pedal keyboard Voice
	Revber Type	Room1、 Room2、 Room3、 Hall1、 Hall2、 Stage1、 Stage2、 Plate
	The adjustable parameters	Dealy、 Mas.level、 Time 、 Feedback
RHYTHM	Chorus Type	Chorus1、 Chorus2、 Chorus3、 Chorus4、 FeedBACK、 Flanger、 ShortDelay、 FB Delay
	The adjustable parameters	Mas.level、 Feedback 、 Rate、 Depth
	IFX EFFECT	WAH Distortion EQ Chorus/flanger/phaser/tremolo/rotary
	Preset rhythm type	191
	Rhythm control	Fade Start/Stop Intro Ending Variation1/2 ManiA/B Synchro Tempo
SEQ	Rhythm part	Drum1, Drum2, Chord1, Chord2, Pad, Phrase1, Phrase2
	Voice selection	√
	Auto bass chord	Turn off Finger Auto Bass
	Chord memory	Lower keyboard、 Pedal keyboard
	Chord chorus	Off、 1、 2、 3、 4 type
PAD	Rhythm sequence design	SEQ1、 SEQ2
	Tone sequence design	Automatic switch
EQ	Supported types	MP3、 MIDI
	The adjustable parameters	Volume
Master Transpose	The adjustable parameters	125Hz、 250Hz、 500Hz、 1kHz、 2kHz、 4kHz、 8kHz
	Keyboard	Transpose
FOOTSWITCH	MIDI Play	USB MIDI transpose
	Left footswitch	Rhythm Start/Stop Variation Ending Sustain
	Right footswitch	Switch to registration memory
	Expression Pedal	Control the strength
	Pitch Pedal	Pitch pedal
Joy Stick	Shake	Pitch
	Up	Modulation
	Down	Cut Off
MIDI Control	MIDI In /MIDI Out	On/Off
USB DISK	Playback options	Play Stop Pause Rew Ff Customize the play Record Registration/MIDI/Audio Speed 50%-200%
	Other features	Playback settings、 selection of folder, file type、 rename , delete the file、 new folder, file order, file copy
Basic Set	Initialization	√
	Display	Display style
	LCD brightness	√
Others	LCD Display	800xRGBx480
	Interface	Phone Micphone LINE IN LINE OUT(L/R) LINE OUT(Balanced) L/R USB to host MIDI IN/OUT Internet
	The power amplifier	90Wx2
	Speaker	BASS: 170mm x 96.5mm Treble: 74mm x 16.5mm monitor : 77mm
	Organ Dimensions	1217*600*1000mm
	Included Accessories	Bench, Owners Guide, USB memory stick (inc bonus registrations)



Official U.K. Dealer

Market Gates Shopping Centre, Great Yarmouth, Norfolk, NR20 2AX

T: 01493 842887 / 850172

W: www.allensmusiccentre.co.uk